

WATER SAMPLE VOLUME

1. We need at least 110ml in order to run an excessive chlorine residual test and coliform test from the sample.
2. Please fill bottle to the neck so it is above the 100ml line.
3. DO NOT fill the bottle to the top as an air gap is needed.

